

# **VigorAccess IVD**

## **CLI Reference Manual**

**Version: 1.2**

**Date: 2007/05/31**

## **Copyright © 2007 by DrayTek Corporation**

All rights reserved. The information of this publication is protected by copyright. No part of this publication may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language without written permission from the copyright holders.

## **Trademark**

DrayTek is a registered trademark of DrayTek Corp. IVD products are trademarks of DrayTek Corp. Other trademarks and registered trademarks of products mentioned in this manual may be the properties of their respective owners and only used for identification purposes.

## **Target Readers**

This guide is intended for those responsible for hardware unpacking and installing for IVD.

# Contents

<b>About This Guide .....</b>	<b>7</b>
<b>Introduction.....</b>	<b>7</b>
<b>1 Introduction.....</b>	<b>8</b>
1.1 Related Documents .....	8
1.2 Structure of a CLI Command.....	8
<b>2 IVD Slave DSL Commands.....</b>	<b>9</b>
2.1 DSL Command List.....	9
2.1.1 How to Monitor DSL Status .....	9
2.1.2 How to Enable/Disable a DSL Port .....	9
2.1.3 How to Read DSL Training Rate .....	9
2.1.4 How to Change ADSL Line Profile .....	10
2.1.5 How to Change ADSL Line Rate.....	10
2.1.6 How to Change ADSL to Fast Channel/Rate .....	10
2.1.7 How to Set ADSL Alarm Profile .....	10
2.1.8 How to Change VPI/CI for Existing VCC.....	10
2.2 Interface Stack (instance number).....	11
2.2.1 How to Change Management IP Address for Existing Ethernet Port.....	11
2.2.2 How to Create more VC/EOA/Bridge .....	11
2.2.3 How to Setup SNMP Community/Host/Trap.....	11
2.2.4 How to Create VLAN .....	11
2.2.5 How to Setup Port VALN ID (PVID) .....	12
2.2.6 How to Filter MAC Address by Port .....	12
2.2.7 How to Deny MAC Address Globally .....	12
2.2.8 How to Filter NetBIOS.....	13
2.2.9 How to Enable Spanning Tree Protocol.....	13
2.2.10 How to Enable IGMP Snooping.....	13
2.2.11 How to Remote Upgrade Control Plane Code .....	14
2.3 How to Save the Latest Configuration .....	15
2.4 How to Remote Upgrade Full Image .....	15
<b>3 IVD Slave VoIP Commands .....</b>	<b>16</b>
3.1 Command Line Introduction .....	16
3.2 Root Commands .....	17
3.2.1 Enter Function Commands .....	17
3.2.2 DSL Module Commands.....	17
3.2.3 Other Commands .....	18
3.3 ACL Commands.....	19

3.3.1 General Commands.....	19
3.3.2 SNMP Access Control List Commands.....	19
3.3.3 Telnet Access Control List Commands .....	20
3.4 Diagnostics Commands .....	21
3.4.1 General Commands.....	21
3.4.2 ARP table Commands .....	21
3.4.3 Learning_table Commands .....	21
3.4.4 Netstat Commands .....	22
3.4.5 Nslookup Commands.....	22
3.4.6 Ping Commands.....	22
3.4.7 Route Commands .....	23
3.4.8 Traceroute Commands.....	23
3.4.7 VLAN_Ping Commands.....	23
3.5 Network Commands .....	24
3.5.1 General Commands.....	24
3.5.2 Dhcpd Commands.....	24
3.5.3 StaticIP Commands .....	24
3.6 QoS Commands .....	25
3.6.1 General Commands.....	25
3.6.2 Bind_VLAN Commands.....	25
3.6.3 ToS_dscp Commands .....	26
3.6.4 VLAN_IP Commands.....	26
3.7 System Commands .....	27
3.7.1 General Commands.....	27
3.7.2 Auto Logout Commands.....	27
3.7.3 Basic Information Commands.....	28
3.7.4 Config Backup/Restore Commands .....	28
3.7.5 Reboot Commands .....	29
3.7.6 Snmpd Commands .....	29
3.7.7 Syslogd Commands.....	30
3.7.8 Upgrade Commands.....	30
3.8 Voip Commands .....	30
3.8.1 General Commands.....	30
3.8.2 Enter Function Commands.....	31
3.8.3 Config Commands .....	31
3.8.4 List Commands .....	31
3.8.5 Protocol Commands .....	32
3.8.6 VoIP Status Commands .....	32
3.9 Linetest Commands.....	33
3.9.1 General Commands.....	33

3.9.2 Line_card_test Commands.....	33
3.9.3 Metallic_loop_test Commands .....	33
3.9.4 User_phone_test Commands.....	34
3.10 MGCP Commands.....	34
3.10.1 General Commands .....	34
3.10.2 Call Agent Commands .....	34
3.10.3 Call Agent2 Commands.....	35
3.10.4 Dual-Homing Commands.....	35
3.10.5 End Point Name ID Style Commands.....	36
3.10.6 MGCP Local Port Commands .....	36
3.10.7 Wildcarded RSIP Commands.....	37
3.11 MISC Commands.....	37
3.11.1 General Commands .....	37
3.11.2 Dialing Timeout Commands .....	37
3.11.3 Failover Commands .....	38
3.11.4 Gain Commands.....	38
3.11.5 LineImpedance Commands.....	39
3.11.6 LineLoopCurrent Commands .....	39
3.11.7 LinePcmCodec Commands.....	40
3.11.8 Metering Commands.....	40
3.11.9 NAT Traversal Commands .....	41
3.11.10 offhookDetect Commands .....	43
3.11.11 Pulsetime Commands.....	43
3.11.12 Ring Candence Commands .....	44
3.11.13 RTP Starting Port Commands.....	44
3.11.14 Sparce Echo Cancellation Commands.....	44
3.11.15 T.38 Starting Port Commands.....	45
3.11.16 T.38 Redundancy Commands.....	45
3.12 SIP Commands.....	46
3.12.1 General Commands .....	46
3.12.2 Enter Function Commands .....	46
3.12.3 Advanced Speed Dial Commands .....	46
3.12.4 Call Forwarding Commands .....	47
3.12.5 Codec Commands.....	48
3.12.6 DTMF Relay Commands .....	49
3.12.7 FAX Commands .....	50
3.12.8 Group Commands .....	50
3.12.9 Hotline Commands.....	51
3.12.10 Local Port Commands .....	52
3.12.11 Phone Number Commands .....	52

3.12.12 Port Proxy Commands .....	53
3.12.13 Server Commands .....	53
3.12.14 Speed Dial Commands .....	54
3.12.15 General Commands .....	55
3.12.16 Allow List Commands .....	55
3.12.17 Deny List Commands .....	56
3.12.18 Set Commands .....	56
3.13 Statistics Commands .....	57
3.13.1 General Commands .....	57
3.13.2 Call Statistics Commands .....	58
3.13.3 RTP Statistics Commands .....	58
3.13.3 RTP threshold Commands .....	59
3.13.5 Show Alert Commands .....	59
3.14 Tone Commands .....	60
3.14.1 General Commands .....	60
3.14.2 Enter Function Commands .....	60
3.14.3 Region Commands .....	60
3.14.4 Busy Tone Commands .....	61
3.14.5 Caller ID Commands .....	62
3.14.6 Congestion Tone Commands .....	62
3.14.7 Dial Tone Commands .....	62
3.14.8 Ringing Tone Commands .....	63
<b>4 IVD Master Commands .....</b>	<b>65</b>
4.1 The General Configuration of IVD Master .....	65
4.1.1 Configure the IP Address .....	66
4.1.2 Upgrade Firmware .....	66
4.1.3 Save the Configuration .....	66
4.1.4 Connect to DSL Module .....	67
4.1.5 ECB Service .....	67

# About This Guide

## Introduction

This document is designed to assist users in using one of the series of high performance IVD. It provides a product overview and hardware architecture descriptions, installation procedures and product features. The command line interface description is also given.

# 1

## Introduction

Welcome to the IVD CLI Reference Manual. The commands and parameters of the Command Line Interface (CLI) to the IVD communication processor are documented in this manual. The CLI enables an administrative user to configure and maintain IVD interfaces, IVD-managed resources and end-customer communication services.

---

### 1.1 Related Documents

---

### 1.2 Structure of a CLI Command

CLI commands conform to the following structure .

**<Action> <value1>..<valueN>**

Consider the CLI command given below:

Figure 1-1:

**<Action>**. This is the first keyword of a CLI command. It indicates the type of operation to be performed. "create" is an example of this keyword. However, if no action is specified it will mean "modify". For example, "modify bridge port intf portid status enable" and "bridge port intf portid portid status enable" mean the same.

**<value1> <valueN>**. These are <value> pairs and can vary from 0 to N. They indicate the parameter values passed to a CLI command.



# 2

## IVD Slave DSL Commands

### 2.1 DSL Command List

#### 2.1.1 How to Monitor DSL Status

Users can use the following command to check the status of DSL. The commands are listed as below:

\$get adsl atuc physical ifname dsl-\* (for downstream)

\$get adsl atur physical ifname dsl-\* (for upstream)

(\*: 0 ~ 23)

#### 2.1.2 How to Enable/Disable a DSL Port

Commands are shown as below:

\$modify adsl line intf ifname dsl-\* enable

\$modify adsl line intf ifname dsl-\* disable

(\*: 0 ~ 23)

#### 2.1.3 How to Read DSL Training Rate

Commands are shown as below:

\$get adsl atuc channel ifname dsli-\* (for downstream/interleave channel)

\$get adsl atur channel ifname dsli-\* (for upstream/fast channel)

\$get adsl atuc channel ifname dsli-\* (for downstream/interleave channel)

\$get adsl atur channel ifname dsli-\* (for upstream/fast channel)

(\*: 0 ~ 23)

## 2.1.4 How to Change ADSL Line Profile

Commands are shown as below:  
`$modify adsl line intf ifname dsl-* disable`  
`$modify adsl line profile ifname dsl-* ?`  
`$modify adsl line intf ifname dsl-* enable`  
 (\*: 0 ~ 23)

## 2.1.5 How to Change ADSL Line Rate

Commands are shown as below:  
`$modify adsl line intf ifname dsl-* disable`  
`$modify adsl line profile ifname dsl-* atucintlmaxtxrate 0x7e0000`  
`$modify adsl line intf ifname dsl-* enable`  
 (\*: 0 ~ 23)

## 2.1.6 How to Change ADSL to Fast Channel/Rate

Commands are shown as below:  
`$modify adsl line intf ifname dsl-* disable`  
`$modify adsl line profile ifname dsl-* type fastOnly`  
`atucfastmaxtxrate 0x7e0000`  
`$modify adsl line intf ifname dsl-* enable`  
 (\*: 0 ~ 23)

## 2.1.7 How to Set ADSL Alarm Profile

Commands are shown as below:  
`$modify adsl line intf ifname dsl-* disable`  
`$modify adsl alarm profile ifname dsl-* ?`  
`$modify adsl line intf ifname dsl-* enable`  
 (\*: 0 ~ 23)

## 2.1.8 How to Change VPI/VCI for Existing VCC

Commands are shown as below:  
`$pvc delete <dsl: 1~24> <pvc: 1~8>`  
`$pvc create <dsl: 1~24> <pvc: 1~8> <vpi> <vci> [<llcmux|vcmux>] [<interleaved|fast>]`

## 2.2 Interface Stack (instance number)

Commands are shown as below:

Bridge Port (1~193)

\_\_\_ Ethernet (1)

\_\_\_ EOA (Ethernet over ATM) (192)

\_\_\_ AAL5 (vpi/vci, fast/interleaved) (192)

\_\_\_ ATM (max VCs) (24)

\_\_\_ DSL (line/alarm profile, ...) (24)

### 2.2.1 How to Change Management IP Address for Existing Ethernet Port

Commands are shown as below:

- a. IVD>network staticIP <new-ip> <mask> <gateway>

### 2.2.2 How to Create more VC/EOA/Bridge

Commands are shown as below:

```
$create atm vc intf ifname aal5-* vpi <vpi> vci <vci> lowif atm-*
[vcmux/lcmux] [fast/interleaved]
$create eoa intf ifname eoa-* lowif aal5-*
$create bridge port intf portid <bridge-port-id> ifname eoa-*
```

### 2.2.3 How to Setup SNMP Community/Host/Trap

Commands are shown as below:

```
$create snmp comm community <community> RW
$create snmp host ip <host-ip> community <community>
$create snmp trap host ip <host-ip> community <community>
```

### 2.2.4 How to Create VLAN

Commands are shown as below:

```
$create vlan static vlnname <vlan-name> valnid <vlan-id>
[egressports <bridge ports>]
```

For example:

- (1) In the IVD console, switch to DSL console

```

IVD>dsl -c

(2) create two pvc of 4th port, 0/35, 8/35
$ pvc create 4 1 0 35
$ pvc create 4 2 8 35

(3) create static vlan group 315 for 4, 304 for 28
$ create vlan static vlanname 315th vlanid 315 egressports 4 193 untaggedports 4
$ create vlan static vlanname 304th vlanid 304 egressports 28 193 untaggedports 28

(4) apply vlan group to pvc
$ gvrp port info portid 4 portvlanid 315
$ gvrp port info portid 28 portvlanid 304

(5) remove port id 4, 28 from default vlan id 1
$ vlan static vlanid 1 egressports 1 2 3 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24
193 untaggedports 1 2 3 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 193

```

## 2.2.5 How to Setup Port VALN ID (PVID)

Commands are shown as below:

```
$ modify gvrp port info portid <bridge-port-id> portvalnid <default-pvid>
```

## 2.2.6 How to Filter MAC Address by Port

Commands are shown as below:

```

$ create acl port macentry portId <bridge-port-id> macaddr 00:00:00:01:02:03
$ create acl port macentry portId <bridge-port-id> macaddr 00:00:00:01:02:04
// allow source address 00:00:00:01:02:03/04 access from bridge port
<bridge-port-id>
// other source addresses from bridge port <bridge-port-id> are denied

```

## 2.2.7 How to Deny MAC Address Globally

Commands are shown as below:

```

$ create acl global macentry macaddr 00:00:00:01:02:03 deny enable
// mac aource address 00:00:00:01:02:03,04 access from any bridge ports is denied

```

## 2.2.8 How to Filter NetBIOS

Commands are shown as below:

```
// NETBIOS-NS Name Service      137    TCP/UDP
// NETBIOS-DGM    Datagram Service    138    TCP/UDP
// NETBIOS-SSN     Session Service139    TCP/UDP
$create filter rule entry ruleid <id> action drop description NETBIOS-TCP
$create filter subrule tcp ruleid <id> subruleid 1
srcportfrom 137 srcportto 139 srcportcmp inrange
$modify filter rule entry ruleid <id> status enable
$create filter rule map ifname all ruleid <id> stageid 1
$create filter rule entry ruleid <id2> action drop description NETBIOS-UDP
$create filter subrule udp ruleid <id2> subruleid 1
srcportfrom 137 srcportto 139 srcportcmp inrange
$modify filter rule entry ruleid <id2> status enable
$create filter rule map ifname all ruleid <id2> stageid 1
```

## 2.2.9 How to Enable Spanning Tree Protocol

Commands are shown as below:

```
// enable STP globally
$modify stp info enable

// bridge port id: 1~24, 193
$modify stp port info portid <bridge-port-id> enable
$get stp port info portid <bridge-port-id>
```

## 2.2.10 How to Enable IGMP Snooping

Commands are shown as below:

```
// NOTE: IGMP Snooping is Factory Default Setting
$create filter rule entry ruleid <id> action sendtocontrol description IGMP
$create filter subrule ip ruleid <id> subruleid 1
prototypefrom 2 prototypecmp eq
$modify filter rule entry ruleid <id> status enable
$create filter rule map ifname all ruleid <id> stageid 1
$modify igmpsnoop cfg info status enable
$modify igmpsnoop port info portid <bridge-port-id> status enable
leavemode fastNormal
or
$modify igmpsnoop port info portid <bridge-port-id> status enable
leavemode Fast
```

## 2.2.11 How to Remote Upgrade Control Plane Code

Commands are shown as below:

- Prepare tftp server
- Prepare vendor supplied CP.bin.gz
- Put CP.bin.gz into root directory of tftp server

\$list

Name	Ver	Time	Size	Acc State
------	-----	------	------	-----------

-----

/nvram/bin/bootptftp/

TftpBootp.bin	1	Mon Aug 23 16:52:58 2004	110008	RO active
---------------	---	--------------------------	--------	-----------

/nvram/bin/control/

CP.bin.gz	1	Mon Aug 23 16:52:58 2004	1467208	RW active
-----------	---	--------------------------	---------	-----------

/nvram/bin/dataplane/

DP.bin.gz	1	Mon Aug 23 16:52:58 2004	252784	RW active
-----------	---	--------------------------	--------	-----------

/nvram/bin/decompressor/

Decompressor.bin	1	Mon Aug 23 16:52:58 2004	81160	RO active
------------------	---	--------------------------	-------	-----------

\$remove fname /nvram/bin/control/CP.bin.gz version 1 <-- depends on real status

\$download src CP.bin.gz dest /nvram/bin/control/CP.bin.gz ip <server-ip>

\$list

Name	Ver	Time	Size	Acc State
------	-----	------	------	-----------

-----

/nvram/bin/bootptftp/

TftpBootp.bin	1	Thu Aug 26 18:31:22 2004	110008	RO active
---------------	---	--------------------------	--------	-----------

/nvram/bin/control/

CP.bin.gz	2	Thu Jan 01 00:13:28 1970	1467204	RW Latest
-----------	---	--------------------------	---------	-----------

/nvram/bin/dataplane/

DP.bin.gz	1	Thu Aug 26 18:31:22 2004	252784	RW active
-----------	---	--------------------------	--------	-----------

/nvram/bin/decompressor/

Decompressor.bin	1	Thu Aug 26 18:31:22 2004	81160	RO active
------------------	---	--------------------------	-------	-----------

NOTE: the Ver of CP.bin.gz becomes 2

NOTE: the State of CP.bin.gz becomes "Latest"

\$upgrade fname /nvram/bin/control/CP.bin.gz version 2 <-- depends on real status

NOTE: the State of CP.bin.gz becomes "active"

\$reboot

---

## 2.3 How to Save the Latest Configuration

Commands are shown as below:  
\$commit

---

## 2.4 How to Remote Upgrade Full Image

Commands are shown as below:

1. Prepare tftp server
2. Prepare vendor supplied DSLImage-A24-A-1GE-2.10.2.8.all
3. Use the CLI command to upgrade firmware.  
\$firmware upgrade [-]DSLImage-A24-A-1GE-2.10.2.8.all <ALL> <server ip>

# 3

## IVD Slave VoIP Commands

---

### 3.1 Command Line Introduction

In addition to the SNMP management, users can use commands to configure the IVD VoIP Board. Users can do telnet on the IVD VoIP Board and use the following two ways. One is console interface; another is telnet by management port.

The IP DSLAM Controller console interface will connect to PC console port. Users can use terminal emulation software configured by the following parameters.

- VT100 terminal emulation
- 9600 bps
- No parity, 8 data bits, 1 stop bit
- No hardware flow control

Users can call type '?' for help. The "IVD> " symbol is just only a prompt.

Another tools for command interface is telnet via management port. The PC should be the same subnet as IVD VoIP Board. The default IP address is 172.16.1.2. The default login name is "**admin**", password is "**1234**".



---

## 3.2 Root Commands

### 3.2.1 Enter Function Commands

- Enter access control list configuration function

**IVD> acl**

- Enter system diagnostics function

**IVD> diag**

- Enter network configuration function

**IVD> network**

- Enter qos configuration function

**IVD> qos**

- Enter system configuration function

**IVD> system**

- Enter voip configuration function

**IVD> voip**

### 3.2.2 DSL Module Commands

- Help

**IVD> dsl ?**

- Login to DSL module in master via serial channel

**IVD> dsl -c**

- Force login to DSL module in master via serial channel

**IVD> dsl -cf**

### 3.2.3 Other Commands

- Help

**IVD> ?**

- Logout the CLI or the Telnet connection

**IVD> exit**

**or**

**IVD> logout**

**or**

**IVD> quit**

## 3.3 ACL Commands

### 3.3.1 General Commands

- Enter access control list configuration function

**IVD> acl**

- Help in the access control list configuration function

**IVD/acl> ?**

- Back to the root commands

**IVD/acl> ..**

### 3.3.2 SNMP Access Control List Commands

- Help

**IVD/acl> snmp ?**

- Display SNMP-ACL settings

**IVD/acl> snmp -s**

- Add the SNMP-ACL entry

**IVD/acl> snmp -a <IP address>**

- Edit the SNMP-ACL entry

**IVD/acl> snmp -e <Index> <IP address>**

- Delete the SNMP-ACL entry

**IVD/acl> snmp -d <Index>**

- Delete all SNMP-ACL entries

**IVD/acl> snmp -D**

### 3.3.3 Telnet Access Control List Commands

- Help

**IVD/acl> telnet ?**

- Display Telnet-ACL settings

**IVD/acl> telnet -s**

- Add the Telnet-ACL entry

**IVD/acl> telnet -a <IP address>**

- Edit the Telnet-ACL entry

**IVD/acl> telnet -e <Index> <IP address>**

- Delete the Telnet-ACL entry

**IVD/acl> telnet -d <Index>**

- Delete all Telnet-ACL entries

**IVD/acl> telnet -D**

---

## 3.4 Diagnostics Commands

### 3.4.1 General Commands

- Enter system diagnostics function

**IVD> diag**

- Help in the system diagnostics function

**IVD/diag> ?**

- Back to the root commands

**IVD/diag> ..**

### 3.4.2 ARP table Commands

- Help

**IVD/diag> arp ?**

- ARP commands usage

**IVD/diag> arp -h**

- ARP table diagnostics utility

**IVD/diag> arp <cmd>**

### 3.4.3 Learning\_table Commands

- Help

**IVD/diag> learning\_table ?**

- Learning\_table commands usage

**IVD/diag> Learning\_table**

### 3.4.4 Netstat Commands

- Help

**IVD/diag> netstat ?**

- Netstat commands usage

**IVD/diag> netstat h**

- Netstat diagnostics utility

**IVD/diag> netstat <cmd>**

### 3.4.5 Nslookup Commands

- Help

**IVD/diag> nslookup ?**

- Nslookup diagnostics utility

**IVD/diag> nslookup <IPorDomainName>**

### 3.4.6 Ping Commands

- Help

**IVD/diag> ping ?**

- Ping commands usage

**IVD/diag> ping**

- Ping diagnostics utility

**IVD/diag> ping <cmd>**

### 3.4.7 Route Commands

- Help

**IVD/diag> route ?**

- Route commands usage

**IVD/diag> route h**

- Route diagnostics utility

**IVD/diag> route <cmd>**

### 3.4.8 Traceroute Commands

- Help

**IVD/diag> traceroute ?**

- Traceroute commands usage

**IVD/diag> traceroute**

- Traceroute diagnostics utility

**IVD/diag> traceroute <cmd>**

### 3.4.7 VLAN\_Ping Commands

- Help

**IVD/diag> vlan\_ping ?**

- Ping commands usage

**IVD/diag> vlan\_ping**

- Ping diagnostics utility

**IVD/diag> vlan\_ping <vlan\_if> <IP\_addr>**

---

## 3.5 Network Commands

### 3.5.1 General Commands

- Enter network configuration function

**IVD> network**

- Help in the network diagnostics function

**IVD/network> ?**

- Back to the root commands

**IVD/network> ..**

### 3.5.2 Dhcp Commands

- Help

**IVD/network> dhcp ?**

- Display the setting

**IVD/network> dhcp -s**

- Enable/Disable the private dhcp client for IVD Master

**IVD/network> dhcp <Active>**

### 3.5.3 StaticIP Commands

- Help

**IVD/network> staticIP ?**

- Display the setting

**IVD/network> staticIP -s**

- Edit the VoIP static IP address, mask and gateway

**IVD/network> staticIP <IP > <Netmask> <Gateway>**

- Edit the VoIP static IP primarydns and secondarydns

**IVD/network> staticIP -n <PrimaryDNS> <SecondaryDNS>**



## 3.6 QoS Commands

### 3.6.1 General Commands

- Enter qos configuration function

**IVD>qos**

- Help in the qos configuration function

**IVD/qos ?**

- Back to the root commands

**IVD/qos ..**

### 3.6.2 Bind\_VLAN Commands

- Help

**IVD/qos> bind\_vlan ?**

- Display the setting

**IVD/qos> bind\_vlan -s**

- Bind MGCP/SIP to specified VLAN Interface

**IVD/qos> bind\_vlan -m <VLAN>**

- Bind RTP to specified VLAN Interface

**IVD/qos> bind\_vlan -r <VLAN>**

- Bind SNMP to specified VLAN Interface

**IVD/qos> bind\_vlan -n <VLAN>**

- Bind Others to specified VLAN Interface

**IVD/qos> bind\_vlan -o <VLAN>**

### 3.6.3 ToS\_dscp Commands

- Help

**IVD/qos> tos\_dscp ?**

- Display the setting

**IVD/qos> tos\_dscp -s**

- Edit the tos/dscp value for RTP, MGCP and SIP

**IVD/qos> tos -v <RTP\_Value> <MGCP\_Value> <SIP\_Value>**

- Edit the tos value for SNMP

**IVD/qos> tos -n <SNMP\_Value>**

<b>Value</b>	Assign a TOS value in VoIP protocol packet. Range: 00 ~ ff (by hex value) (Default is 0xa0)
--------------	------------------------------------------------------------------------------------------------

### 3.6.4 VLAN\_IP Commands

- Help

**IVD/qos> vlan\_ip ?**

- Display the setting

**IVD/qos> vlan-ip -s**

- Edit the VID, Priority, IP Address, Subnet Mask, Default Gateway on VLAN Interface

**IVD/qos> vlan\_ip <Index> <VID> <UserPrio> <IP> <Netmask> <Gateway>**

---

## 3.7 System Commands

### 3.7.1 General Commands

- Enter system configuration function

**IVD> system**

- Help in the system configuration function

**IVD/system> ?**

- Back to the root commands

**IVD/system> ..**

### 3.7.2 Auto Logout Commands

- Help

**IVD/system > auto\_logout ?**

- Display the setting

**IVD/system > auto\_logout -s**

- Edit the max-cli-session number

**IVD/system > auto\_logout -n <MaxSess>**

- Kill the #'s log-session

**IVD/system > auto\_logout -d <SessNum>**

- Edit the maximum idle time of auto logout

**IVD/system > auto\_logout -m <MaxIdleTime>**

- Enable/Disable the auto logout

**IVD/system > auto\_logout <Active>**

### 3.7.3 Basic Information Commands

- Help

**IVD/system> basicInfo ?**

- Display the system information

**IVD/system> basicInfo -s**

- Execute the system Contact command

**IVD/system> basicInfo -c <SysCont>**

- Execute the system Name command

**IVD/system> basicInfo -n <SysName>**

- Execute the system Location command

**IVD/system> basicInfo -l <SysLoc>**

### 3.7.4 Config Backup/Restore Commands

- Help

**IVD/system> config ?**

- Display the setting

**IVD/system> config -s**

- Execute the backup action

**IVD/system> config backup <fname> <servIP>**

- Execute the restore action

**IVD/system> config restore <fname> <servIP>**

### 3.7.5 Reboot Commands

- Help

**IVD/system> reboot ?**

- Reboot the system

**IVD/system> reboot**

- Reboot the system with keeping some important configuration

**IVD/system> reboot keep**

- Reboot the system with factory default configuration

**IVD/system> reboot default**

- Reboot the IVD VOIP board only

**IVD/system> reboot voip**

- Reboot the IVD DSL board only

**IVD/system> reboot dsl**

### 3.7.6 Snmpd Commands

- Help

**IVD/system> snmpd ?**

- Display the community setting

**IVD/system> snmpd -s**

- Edit the traphost setting

**IVD/system>snmpd -h <traphost>**

- Edit the community setting

**IVD/system> snmpd -c <CommRO> <CommRW> <CommTrap>**

### 3.7.7 Syslogd Commands

- Help

**IVD/system> syslogd ?**

- Display the syslog setting

**IVD/system> syslogd -s**

- Edit the syslog setting

**IVD/system> syslogd <Active> <RIP> <RPort>**

### 3.7.8 Upgrade Commands

- Help

**IVD/system> upgrade ?**

- Display the setting

**IVD/system> upgrade -s**

- Execute the firmware upgrade

**IVD/system> upgrade <File Name> <Server IP>**

---

## 3.8 Voip Commands

### 3.8.1 General Commands

- Enter voip configuration function

**IVD> voip**

- Help in the voip diagnostics function

**IVD/voip> ?**

- Back to the root commands

**IVD/voip> ..**

### 3.8.2 Enter Function Commands

- Enter linetest configuration function

**IVD> voip>linetest**

- Enter mgcp configuration function

**IVD> voip>mgcp**

- Enter voip miscellaneous configuration function

**IVD/voip>misc**

- Enter sip configuration function

**IVD/voip>sip**

- Enter voip statistics configuration function

**IVD/voip>statistics**

- Enter voip tone configuration function

**IVD/voip>tone**

### 3.8.3 Config Commands

- Help

**IVD/voip> config ?**

- To activate voip configuration

**IVD/voip> config activate**

### 3.8.4 List Commands

- Help

**IVD/voip> listcmds ?**

- Show all voip commands

**IVD/voip> listcmds**

### 3.8.5 Protocol Commands

- Help

**IVD/voip>protocol ?**

- Display the setting

**IVD/voip>protocol -s**

- Choose the voip protocol

**IVD/voip>protocol <Protocol>**

<b>Select Protocol</b>	Users can choose one of two protocols, one is <b>SIP</b> , and the other is <b>MGCP</b> . The default setting is <b>SIP</b> .
------------------------	-------------------------------------------------------------------------------------------------------------------------------

### 3.8.6 VoIP Status Commands

- Help

**IVD/voip> status ?**

- Show voip status of port#

**IVD/voip> status <Port>**

- Show all voip status

**IVD/voip> status**

<b>Register Status</b>	It shows the status of registering in proxy server.
<b>Call Status</b>	It shows the calling status.
<b>Call Type</b>	It shows the dialing direction for this phone calling.
<b>Caller Number</b>	It shows the phone number of caller.
<b>Callee Number</b>	It shows the phone number of calling receiver.
<b>Start Time</b>	It shows the starting time of calling.
<b>Remote RTP Address</b>	It shows the IP address of remote voice site.
<b>Remote RTP Port</b>	It shows the used port number of remote voice site.
<b>RTP Statistic</b>	It shows the RTP Statistic.



<b>Codec Type</b>	It shows the Codec mode used for this phone calling.
<b>Packet Period</b>	It shows the period of time for sampling on voice signal.
<b>VAD</b>	It shows the status of VAD.
<b>DTMF Relay</b>	It shows the status of DTMF.

## 3.9 Linetest Commands

### 3.9.1 General Commands

- Enter linetest configuration function

**IVD/voip> linetest**

- Help in the linetest diagnostics function

**IVD/voip/linetest> ?**

- Back to the voip commands

**IVD/voip/ linetest > ..**

### 3.9.2 Line\_card\_test Commands

- Help

**IVD/voip/ linetest > line\_card\_test ?**

- Execute voip line\_card\_test

**IVD/voip/ linetest > line\_card\_test <Line> <TestItem>**

### 3.9.3 Metallic\_loop\_test Commands

- Help

**IVD/voip/ linetest >metallic\_loop\_test ?**

- Execute voip metallic\_loop\_test

**IVD/voip/ linetest > metallic\_loop\_test <Line> <TestItem>**

### 3.9.4 User\_phone\_test Commands

- Help

IVD/voip/ linetest >user\_phone\_test ?

- Execute voip user\_phone\_test

IVD/voip/ linetest > user\_phone\_test <Line> <TestItem>

## 3.10 MGCP Commands

### 3.10.1 General Commands

- Enter mgcp configuration function

IVD/voip> mgcp

- Help in the mgcp diagnostics function

IVD/voip/mgcp> ?

- Back to the voip commands

IVD/voip/mgcp> ..

### 3.10.2 Call Agent Commands

- Help

IVD/voip/mgcp> callagent ?

- Display the setting

IVD/voip/mgcp> callagent -s

- Edit the IP address and port number for call agent

IVD/voip/mgcp> callagent <IPAddress> <Port>

<b>MGCP Call Agent IP Address</b>	Assign an IP address of Call Agent server in MGCP. (Default is 192.168.100.100)
<b>MGCP Call Agent Port</b>	Assign a UDP port number to Call Agent server. 1...65535 (Default is 2727)

### 3.10.3 Call Agent2 Commands

- Help

**IVD/voip/mgcp> callagent2 ?**

- Display the setting

**IVD/voip/mgcp> callagent2 -s**

- Edit the IP address and port number for call agent2

**IVD/voip/mgcp> callagent2 <IPAddress> <Port>**

<b>MGCP Call Agent2 IP Address</b>	Assign an IP address of Call Agent2 server in MGCP.
<b>MGCP Call Agent2 Port</b>	Assign a UDP port number to Call Agent2 server.

### 3.10.4 Dual-Homing Commands

- Help

**IVD/voip/mgcp> dual\_homing ?**

- Display the setting

**IVD/voip/mgcp> dual\_homing -s**

- Edit the dual\_homing action

**IVD/voip/mgcp> dual\_homing <Active>**

- Edit the period of heartbeat for dual\_homing

**IVD/voip/mgcp> dual\_homing -t <Sec>**

- Edit the retry times of dual\_homing

**IVD/voip/mgcp> dual\_homing -r <Times>**

<b>MGCP Dual Homing Action</b>	It shows the dual homing action.
<b>MGCP Dual Homing Period</b>	Setting the period of dual homing.
<b>MGCP Dual Homing Retry Times</b>	Setting the retry times of dual homing.

### 3.10.5 End Point Name ID Style Commands

- Help

**IVD/voip/mgcp> epidstyle ?**

- Display the setting

**IVD/voip/mgcp> epidstyle -s**

- Edit the style mode for end point

**IVD/voip/mgcp> epidstyle <Mode>**

- Edit the port number base id for end point

**IVD/voip/mgcp> epidstyle -b <BaseNum>**

- Edit the domain name for end point

**IVD/voip/mgcp> epidstyle -m <DomainName>**

<b>EndPoint Name Style</b>	<p>There are four options for users to select.</p> <p><b>0. <u>aaln/#@[ip_addr]</u>      ex: aaln/1@[1.1.1.1]</b></p> <p><b>1. <u>mac_addr/#@[ip_addr]</u>   ex: 000504030201/1@[1.1.1.1]</b></p> <p><b>2. <u>aaln/#@mac_addr</u>        ex: aaln/1@000504030201</b></p> <p><b>3. <u>aaln/#@domain_name</u>    ex: <u>aaln/1@callagent.com</u></b></p> <p>(Default is 0)</p>
----------------------------	------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

### 3.10.6 MGCP Local Port Commands

- Help

**IVD/voip/mgcp> localport ?**

- Display the setting

**IVD/voip/mgcp> localport -s**

- Edit the local port number for MGCP protocol

**IVD/voip/mgcp> localport <Port>**

<b>MGCP Call Agent Port</b>	Assign a UDP port number to Call Agent server. 1...65535 (Default is 2427)
-----------------------------	-------------------------------------------------------------------------------

### 3.10.7 Wildcarded RSIP Commands

- Help

**IVD/voip/mgcp> wildrsip ?**

- Display the setting

**IVD/voip/mgcp> wildrsip -s**

- Setting the wildcarded RSIP action

**IVD/voip/mgcp> wildrsip <Active>**

<b>Active</b>	There are two options for users to select. <b>Each endpoint sends its own RSIP</b> <b>Send only one wild-carded RSIP</b> "Enable" to activate this function. "Disable" to close this function. (Default is Disable)
---------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

---

## 3.11 MISC Commands

### 3.11.1 General Commands

- Enter misc configuration function

**IVD/voip>misc**

- Help in the misc diagnostics function

**IVD/voip/misc> ?**

- Back to the voip commands

**IVD/voip/misc> ..**

### 3.11.2 Dialing Timeout Commands

- Help

**IVD/voip/misc> dialing\_timeout ?**

- Display the setting

**IVD/voip/misc> dialing\_timeout -s**

- Edit the dialing completion timeout value

**IVD/voip/misc> dialing\_timeout <value>**

<b>Value</b>	1~60 (unit is second) (Default is 4)
--------------	--------------------------------------

### 3.11.3 Failover Commands

- Help

**IVD/voip/misc> failover ?**

- Display the setting

**IVD/voip/misc> failover -s**

- Enable/Disable fail-over when network is disconnected

**IVD/voip/misc> failover -n <Mode>**

- Force to use phone interface

**IVD/voip/misc> failover -f <Mode>**

### 3.11.4 Gain Commands

- Help

**IVD/voip/misc> gain ?**

- Display the setting

**IVD/voip/misc> gain -s**

- Edit the speaker and microphone gain

**IVD/voip/misc> gain <Device port> <Speaker Gain> <Microphone Gain>**

<b>Device port</b>	Device port number (1~24).
<b>Speaker Gain</b>	Assign the gain value while receiving voice, default value is 0. The range is from -14 to 6. (Default is 0)
<b>Microphone Gain</b>	Assign the gain value while transmitting voice, default value is 0. The range is from -14 to 6. (Default is 0)

### 3.11.5 LineImpedance Commands

- Help

**IVD/voip/misc> lineImpedance ?**

- Display the setting

**IVD/voip/misc> lineImpedance -s**

- Set the same value for each line

**IVD/voip/misc> lineImpedance <Country>**

- Set the value for the port

**IVD/voip/misc> lineImpedance <line> <Country>**

<b>line</b>	Device line number (1~24)
<b>Country</b>	0: 600 Ohm (default) 1: 900 Ohm 2: China

### 3.11.6 LineLoopCurrent Commands

- Help

**IVD/voip/misc> lineLoopCurrent ?**

- Display the setting

**IVD/voip/misc> lineLoopCurrent -s**

- Set the same value for each line

**IVD/voip/misc> lineLoopCurrent <Current>**

- Set the value for the line

**IVD/voip/misc> lineLoopCurrent <line> <Current>**

<b>Line</b>	Device line number(1~24)
<b>Current</b>	25:25 mA (default) 20:20 mA

### 3.11.7 LinePcmCodec Commands

- Help

**IVD/voip/misc> linePcmCodec ?**

- Display the setting

**IVD/voip/misc> linePcmCodec -s**

- Set the same value for each line

**IVD/voip/misc> linePcmCodec <codec>**

- Set the value for the line

**IVD/voip/misc> linePcmCodec <line> <codec>**

<b>Line</b>	Device line number(1~24)
<b>codec</b>	0: Mu-LAW (default) 1: A-LAW

### 3.11.8 Metering Commands

- Help

**IVD/voip/misc> metering ?**

- Display the setting

**IVD/voip/misc> metering -s**



- Setting Metering mode

**IVD/voip/misc> metering -m <Metering Mode>**

- Setting Reversal mode

**IVD/voip/misc> metering -r <Reversal Mode>**

<b><i>Metering Mode</i></b>	0:Line polarity reversal (default) 1:12KHZ Tone 2:16KHZ Tone
<b><i>Reversal Mode</i></b>	0: Reverse as peer end-point On-hook (default) 1: Reverse as callee Off-hook

### 3.11.9 NAT Traversal Commands

- Help

**IVD/voip/misc> nat ?**

- Display the setting

**IVD/voip/misc> nat -s**

- Disable NAT traversal function

**IVD/voip/misc> nat <Disable Mode>**

- Enable Manual mode and WAN IP Address for NAT router

**IVD/voip/misc> nat <Manual Mode> <NatIpAddr>**

- Enable Auto mode and related parameters

**IVD/voip/misc> nat <Auto Mode> <Type> <LocalPort> <ServerIP> <ServerPort>**

- Edit symmetric media setting

**IVD/voip/misc> nat -sym <sym\_rtp\_t38>**

<b>Disable</b>	<p>Disable this function. The application is IVD has a public WAN IP address.</p> <p>(not behind a NAT router)</p> <p>0: Disable NAT traversal (Default is 0)</p> <p>1: Manually input NAT IP address</p> <p>2: Auto discover NAT IP address</p>
<b>Manually Input NAT IP Address</b>	
<b>NAT IP Address</b>	<p>Assign an IP address as NAT IP address.</p> <p>The application is when IVD is behind a NAT router, and NAT router uses a static WAN IP address. This value is same as WAN IP in NAT router.</p> <p>(Default is 172.0.0.1)</p>
<b>Auto Discovery NAT IP Address</b>	
<b>STUN Local Port</b>	<p>Assign a port number of STUN server.</p> <p>(Default is 3478)</p>
<b>STUN Server Address</b>	<p>Assign an IP address of STUN server.</p> <p>(Default is stun.fwdnet.net)</p>
<b>STUN Server Port</b>	<p>Assign a server port number of STUN server.</p> <p>(Default is 3478)</p>
<b>Type</b>	<p>0: Semi-auto (need to configure NAT)</p> <p>1: Full-auto (no need to configure NAT) (Default is 1)</p>
<b>Sym_Rtp_T38</b>	<p>Symmetric Media Setting</p> <p>0: Disable symmetric RTP and T.38 (Default is 0)</p> <p>1: Enable symmetric RTP and T.38</p>

**Note:** “Auto Discovery NAT IP Address” option is used when IVD is behind a NAT router, NAT uses dynamic WAN IP address like as DHCP or PPPoE client. There must be having a STUN server in Internet. IVD needs to negotiate with STUN server for this function.

**Note:** The “STUN”(Simple Traversal of UDP through NATs) server is an implementation of the STUN protocol that enables STUN functionality in SIP-based systems. STUN is an application-layer protocol that can determine the public IP and nature of a NAT device that sits between the STUN client and STUN server.

### 3.11.10 offhookDetect Commands

- Help

**IVD/voip/misc>offhookDetect ?**

- Display the setting

**IVD/voip/misc>offhookDetect -s**

- Set the same value for each line

**IVD/voip/misc> offhookDetect <Current>**

- Set the calue for the line

**IVD/voip/misc> offhookDetect <line> <Current>**

<b><i>Line</i></b>	Device line number(1~24)
<b><i>Current</i></b>	8: 8 mA (default) 10: 10 mA 12: 12 mA

### 3.11.11 Pulsetime Commands

- Help

**IVD/voip/misc>pulsetime ?**

- Display the setting

**IVD/voip/misc> pulsetime -s**

- Set these value for pulse time

**IVD/voip/misc> pulsetime <breakMin> <breakMax> <flashMin> <flashMax> <makeMin>  
<makeMax> <interDigitMin>**

<b><i>breakMin</i></b>	Minimum pulse break time (ms)
<b><i>breakmax</i></b>	Maximum pulse break time (ms)
<b><i>flashMin</i></b>	Minimum flash break time (ms)
<b><i>flashmax</i></b>	Maximum flash break time (ms)

<b><i>makeMin</i></b>	Minimum pulse make time (ms)
<b><i>makeMax</i></b>	Maximum pulse make time (ms)
<b><i>interDigitMin</i></b>	Minimum pulse interdigit time (ms)
<b>1.breakMin &lt; breakMax &lt; flashMin &lt; flashMax</b> <b>2.makeMin &lt; makeMax &lt; interDigitMin</b>	

### 3.11.12 Ring Candence Commands

- Help

**IVD/voip/misc>ring\_cadence ?**

- Display the setting

**IVD/voip/misc> ring\_cadence -s**

- Edit the 8 different patterns of distinctive ringing

**IVD/voip/misc> ring\_cadence <Index> <Ton1> <Toff1> <Ton2> <Toff2>  
<Ton3> <Toff3> <Ton4> <Toff4>**

### 3.11.13 RTP Starting Port Commands

- Help

**IVD/voip/misc> rtp\_port ?**

- Display the setting

**IVD/voip/misc> rtp\_port -s**

- Edit the rtp starting port

**IVD/voip/misc> rtp\_port <Port number>**

<b><i>Port number</i></b>	Assign a starting port number in RTP protocol packet. 1...65535. (Default is 13456)
---------------------------	----------------------------------------------------------------------------------------

### 3.11.14 Sparce Echo Cancellation Commands

- Help

**IVD/voip/misc> sparceEC ?**

- Display the setting

**IVD/voip/misc> sparceEC -s**

- Edit the SparceEC active

**IVD/voip/misc> sparceEC <enable>**

-Edit Network Echo Canceller Tail Lenth

**IVD/voip/misc> sparceEC <enable> <tailLenth>**

<b>enable</b>	0: disable 1: enable
<b>tailLenth</b>	Range: 8~128, should be multiple of 8

### 3.11.15 T.38 Starting Port Commands

- Help

**IVD/voip/misc> t38port ?**

- Display the setting

**IVD/voip/misc> t38port -s**

- Edit the T.38 starting port

**IVD/voip/misc> t38port <port>**

<b>port</b>	Assign a starting port number in T.38 protocol packet. 1...65535 (Default is 49170)
-------------	----------------------------------------------------------------------------------------

### 3.11.16 T.38 Redundancy Commands

- Help

**IVD/voip/misc> t38redundancy ?**

- Display the setting

**IVD/voip/misc> t38redundancy -s**

- Edit the T.38 redundancy number

**IVD/voip/misc> t38redundancy <Number>**

<b>Number</b>	Assign a redundancy number in T.38 protocol. It means how many payloads to be attached in the tail of packet.  0~4 (Default is 1)
---------------	-----------------------------------------------------------------------------------------------------------------------------------------

---

## 3.12 SIP Commands

### 3.12.1 General Commands

- Enter sip configuration function

**IVD/voip> sip**

- Help in the sip configuration function

**IVD/voip/sip> ?**

- Back to the voip commands

**IVD/voip/sip> ..**

### 3.12.2 Enter Function Commands

- Enter incallbarring configuration function

**IVD/voip/sip> incallbarring**

### 3.12.3 Advanced Speed Dial Commands

- Help

**IVD/voip/sip> advspdial ?**

- Display the setting

**IVD/voip/sip> advspdial -s**

- Add prefix, strip length, append number, destination and memo for the entry

**IVD/voip/sip> advspdial -a <Prefix> <Strip> <Append> <Destination> <Memo>**

- Edit prefix, strip length, append number, destination and memo for the entry

**IVD/voip/sip> advspdial -e <EntryIdx> <Prefix> <Strip> <Append> <Destination> <Memo>**

- Delete the entry

**IVD/voip/sip> advspdial -d <EntryIdx>**

- Delete all entries

**IVD/voip/sip> advspdial -D**

<b>EntryIdx</b>	1~30
<b>Prefix</b>	Prefix number, ex: 101 (Default is none)
<b>Strip</b>	Strip length (Default is none)
<b>Append</b>	Append number (Default is none)
<b>Destination</b>	IP or Domain name (Default is none)
<b>Memo</b>	Free text (Default is none)

### 3.12.4 Call Forwarding Commands

- Help

**IVD/voip/sip> callforward ?**

- Display the setting

**IVD/voip/sip> callforward -s**

- Edit call forwarding mode

**IVD/voip/sip> callforward <Port> <Mode>**

- Edit call forwarding mode and SIP URL

**IVD/voip/sip> callforward <Port> <Mode> <SipURL>**

- Edit call forwarding mode, SIP URL and ringing number for no answer

**IVD/voip/sip> callforward <Port> <Mode> <SipURL> <NoAnswerRings>**

<b>Port</b>	device port number (1~24)
<b>Mode</b>	0: Disable (Default is 0) 1: Call forwarding all calls 2: Call forwarding busy 3: Call forwarding no answer
<b>SIP URL</b>	sip url format, ex: <u>101@iptel.org</u> (Default is none)
<b>NoAnswerRings</b>	1~10 (ringing times) (Default is 3)

### 3.12.5 Codec Commands

- Help

**IVD/voip/sip> codec ?**

- Display the setting

**IVD/voip/sip> codec -s**

- Edit prefect codec, codec rate and VAD for the port#

**IVD/voip/sip> codec <Port> <PreferCodec> <CodecRate> <VAD>**

- Edit single codec for the port#

**IVD/voip/sip> codec -single <Port> <Active>**

<b>Port</b>	Device port number (1~24)
<b>Preferred Codec</b>	Select one Codec to be applied on this port. IVD supports five Codecs. 0: G.711U(PCMU) -64kbps 1: G.711A(PCMA) -64kbps 2: G.729A -8kbps (Default is 2) 3: G.723.1 -6.3kbps 4: G.726-32kbps
<b>Codec Rate</b>	Select one rate value to be applied on this port. 20/40 - for PCMU or PCMA (Default is 20) 20/40/60/80 - for G.729A (Default is 20) 30/60 - for G.723.1 (Default is 30)



	20/40 - for G.726 (Default is 20)
<b>VAD</b>	<p><b>"Enable"</b> to activate VAD(Voice Activity Detection, also known as Silence Suppression) function.</p> <p><b>"Disable"</b> to stop using VAD. (Default is Disable)</p>
<b>Active</b>	<p><b>"Enable"</b> to activate this port.</p> <p><b>"Disable"</b> to close this port. (Default is Disable)</p>

### 3.12.6 DTMF Relay Commands

- Help

**IVD/voip/sip> dtmf\_relay ?**

- Display the setting

**IVD/voip/sip> dtmf\_relay -s**

- Edit dtmf relay mode for the port#

**IVD/voip/sip> dtmf\_relay <Port> <Mode>**

- Edit dtmf relay mode and SIP INFO mode for the port#

**IVD/voip/sip> dtmf\_relay <Port> <Mode> <SipInfoMode>**

<b>Port</b>	Device port number (1~24)
<b>Mode</b>	0: Disable 1: RFC2833 (Default is 1) 2: SIP INFO
<b>SipInfoMode</b>	Click one option to be applied in DTMF function. There are three options to be supported as below – <b>Disable(Inband)</b> <b>RFC2833</b> <b>SIP INFO</b> 0: CISCO 1: NORTEL (If Mode is 1, default is none) (If Mode is 2, default is 0)

### 3.12.7 FAX Commands

- Help

**IVD/voip/sip> fax ?**

- Display the setting

**IVD/voip/sip> fax -s**

- Edit fax mode for the port#

**IVD/voip/sip> fax <Port> <Mode>**

<b>Port</b>	Device port number (1~24)
<b>Mode</b>	<p>Select a mode to be applied on FAX function. There are two options to be supported as below –</p> <p><b>Transparent : FAX will be transmitted via voice channel, no fax relay nor Codec change will be involved.</b></p> <p><b>T.38 Relay : Using T.38 Fax Relay.</b> It is the default value.</p> <p>0: Transparent</p> <p>1: T.38 Relay (Default is 1)</p>

### 3.12.8 Group Commands

- Help

**IVD/voip/sip> group ?**

- Display the setting

**IVD/voip/sip> group -s**

- Enable/Disable group function and edit ring type

**IVD/voip/sip> group <Active > <Rings>**

- Edit the group number for the port

**IVD/voip/sip> group -p <Port> <Group>**

<b>Active</b>	<p>0: Disable (Default is 0)</p> <p>1: Enable</p>
<b>Rings</b>	0: Rings all ports in the group

	1: Rings the first available port 2: Rings by round robin (Default is 2)
<b>Port</b>	Assign a port number (1~24) (Default is 1~24 mapped to 1~ 24 port)
<b>Group</b>	Assign a group number for assigned port (1~24) (Default is 1~24 mapped to 1~ 24 port)

**Note** - It is very important to provide Group function for voice service in company. Customers can simultaneously call a same phone number to destination. When IVD gets a phone which configured in the first port of a group from Internet, IVD will ring all available ports belonged to this group to provide voice service at the same time. It is the benefit for customer to remember one phone number corresponding to one company. Users can configure 24 groups at most and select each phone line belongs to one specific group. Each phone line is only for one group and not permitted to be overlapped.

### 3.12.9 Hotline Commands

- Help

**IVD/voip/sip> hotline ?**

- Display the setting

**IVD/voip/sip> hotline -s**

- Enable/Disable the hotline function

**IVD/voip/sip> hotline <Port> <Active>**

- Edit the hotline number

**IVD/voip/sip> hotline <Port> <Active> <<Digits>**

Port	device port number (1~24)
Active	“ <b>Enable</b> ” to activate this function. “ <b>Disable</b> ” to close this function. (Default is Disable)
Digits	Default is none

### 3.12.10 Local Port Commands

- Help

**IVD/voip/sip> localport ?**

- Display the setting

**IVD/voip/sip> localport -s**

- Edit sip local port number

**IVD/voip/sip> localport <Port> 1...65535 (Default is 5060)**

### 3.12.11 Phone Number Commands

- Help

**IVD/voip/sip> phonenummer ?**

- Display the setting

**IVD/voip/sip> phonenummer -s**

- Enable/Disable the port#

**IVD/voip/sip> phonenummer <Port> <Active>**

- Edit phone number, password, display name and authentication id for port#

**IVD/voip/sip> phonenummer <Port> <Active> <PhoneNum> <Password>  
<DisplayName> <AuthID>**

<b>Port</b>	Device port number (1~24).
<b>Active</b>	<p>“Enable” to activate this port.</p> <p>“Disable” to close this port.</p>
<b>PhoneNum</b>	<p>Assign a number as a user name for each phone line.</p> <p>(Default is 1001~1024 mapped to 1~24 port)</p>
<b>Password</b>	<p>Assign a user password for each phone line.</p> <p>(Default is 0000)</p>
<b>Display Name</b>	<p>Assign a user name to be displayed on another phone terminal.</p> <p>(Default is 1001~1024 mapped to 1~24 port)</p>
<b>AuthID</b>	<p>Assign a auth ID to authenticate with proxy server.</p> <p>(Default is 1001~1024 mapped to 1~24 port)</p>

### 3.12.12 Port Proxy Commands

- Help

**IVD/voip/sip> portproxy ?**

- Display the setting

**IVD/voip/sip> portproxy -s**

- Choose proxy for the port

**IVD/voip/sip> portproxy <Port> <Proxy#>**

### 3.12.13 Server Commands

- Help

**IVD/voip/sip> server ?**

- Display the setting

**IVD/voip/sip> server -s**

- Enable/Disable the proxy server

**IVD/voip/sip> server <Proxy#> <Active>**

- Enable/Disable the proxy server and outbound proxy

**IVD/voip/sip> server <Proxy#> <Active> <Outbound>**

- Edit the proxy server parameters

**IVD/voip/sip> server <Proxy#> <Active> <Outbound> <ProxyName> <ProxyIP>  
<ProxyPort> <RegistrarIP> <RegistrarPort> <Expires> <Domain>**

<b>Proxy#</b>	Proxy # is from 1 to 3.
<b>Active</b>	0: Disable (Default is 0) 1: Enable
<b>Outbound</b>	0: Disable (Default is 0) 1: Enable (It means that each SIP protocol packet will be sent to SIP proxy server always.)
<b>ProxyName</b>	Assign a name of SIP proxy server. (Default is none)
<b>ProxyIP</b>	Assign an IP address of SIP proxy server. (Default is 0)

<b>ProxyPort</b>	Assign a port number of SIP proxy server. 1...65535 (Default is 5060)
<b>RegistrarIP</b>	Assign an IP address or domain name of SIP register server. (Default is 0)
<b>RegistrarPort</b>	Assign a port number of SIP register server. 1...65535 (Default is 5060)
<b>Expires</b>	Assign a timeout value for SIP protocol, the default value is 300. (minimum 60 seconds)
<b>Domain</b>	Assign an IP address or domain name of SIP Domain/Realm. (Default is 0)

### 3.12.14 Speed Dial Commands

- Help

**IVD/voip/sip> speeddial ?**

- Display the setting

**IVD/voip/sip> speeddial -s**

- Add speeddial number and destination for the entry

**IVD/voip/sip> speeddial -a <Number> <Destination> <Memo>**

- Edit speeddial number, destination and memo for the entry

**IVD/voip/sip> speeddial -e <Index> <Number> <Destination> <Memo>**

- Delete the entry

**IVD/voip/sip> speeddial -d <Index>**

- Delete all entries

**IVD/voip/sip> speeddial -D**

<b>Index</b>	1~150
<b>Number</b>	Assign a dialing phone number.Ex: 101
<b>Destination</b>	Assign an address of dialing destination. Ex: <u>101@iptel.org</u>
<b>Memo</b>	Users can add some descriptions for each number. (Default is none)

### 3.12.15 General Commands

- Enter incallbarring configuration function

**IVD/voip/sip>incallbarring**

- Help in the incallbarring configuration function

**IVD/voip/sip/incallbarring> ?**

- Back to the sip commands

**IVD/voip/sip/incallbarring> ..**

### 3.12.16 Allow List Commands

- Help

**IVD/voip/sip/incallbarring> allow ?**

- Display the setting

**IVD/voip/sip/incallbarring> allow -s**

- Add the index entry in the allow list

**IVD/voip/sip/incallbarring> allow -a <Name> <IP/Domain>**

- Edit the index entry in the allow list

**IVD/voip/sip/incallbarring> allow -e <Index> <Name> <IP/Domain>**

- Delete the index entry in the allow list

**IVD/voip/sip/incallbarring> allow -d <Index>**

- Delete all entries

**IVD/voip/sip/incallbarring> allow -D**

<b>Index</b>	1~30 (Default is none)
<b>Name</b>	Assign a name or number in allow list. Free text (Default is none)
<b>IP/Domain</b>	Assign an IP address or domain name in allow list. If the other side had registered in SIP proxy server, please type the domain name of SIP

proxy server.
---------------

If the other side had not registered in SIP proxy server, please type the static IP address or DDNS domain name.
------------------------------------------------------------------------------------------------------------------

ex: 192.168.1.1/iptel.org (Default is none)
---------------------------------------------

### 3.12.17 Deny List Commands

- Help

**IVD/voip/sip/incallbarring> deny ?**

- Display the setting

**IVD/voip/sip/incallbarring> deny -s**

- Add the index entry in the deny list

**IVD/voip/sip/incallbarring> deny -a <Name> <IP/Domain>**

- Edit the index entry in the deny list

**IVD/voip/sip/incallbarring> deny -e <Index> <Name> <IP/Domain>**

- Delete the index entry in the deny list

**IVD/voip/sip/incallbarring> deny -d <Index>**

- Delete all entries

**IVD/voip/sip/incallbarring> deny -D**

<b>Name</b>	Assign a name in deny list.
<b>IP/Domain</b>	Assign an IP address or domain name in deny list.  If the other side had registered in SIP proxy server, please type the domain name of SIP proxy server.  If the other side had not registered in SIP proxy server, please type the static IP address or DDNS domain name.

### 3.12.18 Set Commands

- Help

**IVD/voip/sip/incallbarring> set ?**



- Display the setting

**IVD/voip/sip/incallbarring> set -s**

- Edit the class, match mode and speeddial entries

**IVD/voip/sip/incallbarring> set <Class> <MatchName> <MatchIP> <SpeeddialFrom>  
<SpeeddialTo>**

<b>Class</b>	There are five options users can use. 0: Allow all incoming calls. (Default is 0) 1: Allow only calls from allow list. 2: Allow only calls from speed dial entries. 3: Deny only calls from deny list. 4: Deny all incoming calls.
<b>Match Method</b>	
<b>MatchName</b>	“Disable” to disable this field mapped in speed dial table as “Speed Dial Phone Number” to be checked. “Enable” to enable this field mapped in speed dial table as “Speed Dial Phone Number” to be checked. (Default is Enable)
<b>MatchIP</b>	“Disable” to disable this field mapped in speed dial table as “Speed Dial Destination” to be checked. “Enable” to enable this field mapped in speed dial table as “Speed Dial Destination” to be checked. (Default is Enable)
<b>SpeeddialFrom</b>	1~150 (Default is 1)
<b>SpeeddialTo</b>	1~150 (Default is 150)

## 3.13 Statistics Commands

### 3.13.1 General Commands

- Enter statistics configuration function

**IVD/voip>statistics**

- Help in the statistics diagnostics function

**IVD/voip>statistics ?**

- Back to the voip commands

**IVD/voip/tone> ..**

### 3.13.2 Call Statistics Commands

- Help

**IVD/voip/statistics> callstat ?**

- Display the setting

**IVD/voip/statistics> callstat**

- Display the setting by port

**IVD/voip/statistics> callstat <Port>**

- Edit the range for callstat port

**IVD/voip/statistics> callstat <Port> <Range>**

<b>Port</b>	<b>Device port number (1~24)</b>
<b>Range</b>	<b>0: 15 minutes</b> <b>1: 24 hour</b>

### 3.13.3 RTP Statistics Commands

- Help

**IVD/voip/statistics> rtpstat ?**

- Display the setting

**IVD/voip/statistics> rtpstat**

- Display the setting by port

**IVD/voip/statistics> rtpstat <Port>**

- Edit the range for rtpstat port

**IVD/voip/statistics> rtpstat <Port> <Range>**

<b>Port</b>	<b>Device port number (1~24)</b>
<b>Range</b>	<b>0: 15 minutes</b> <b>1: 24 hour</b>

### 3.13.3 RTP threshold Commands

- Help

**IVD/voip/statistics> rtpthreshold ?**

- Display the setting

**IVD/voip/statistics> rtpthreshold -s**

- Edit the value for rtpthreshold

**IVD/voip/statistics> rtpthreshold <mode> <delayLow> <delayHigh> <jitterLow> <jitterHigh>  
<lostLow> <lostHigh> <timeout>**

<b>mode</b>	<b>0: disable</b> <b>1: enable</b>
<b>delayLow</b>	<b>Round Trip Delay Low Threshold (ms)</b>
<b>delayHigh</b>	<b>Round Trip Delay High Threshold (ms)</b>
<b>jitterLow</b>	<b>Jitter Low Threshold (ms)</b>
<b>jitterHigh</b>	<b>Jitter High Threshold (ms)</b>
<b>lostLow</b>	<b>Packet Loss Ratio Low Threshold (0..100%)</b>
<b>lostHigh</b>	<b>Packet Loss Ratio High Threshold (0..100%)</b>
<b>timeout</b>	<b>RTCP timeout (in seconds)</b>

### 3.13.5 Show Alert Commands

- Help

**IVD/voip/statistics> showalert ?**

- Display all port setting

**IVD/voip/statistics> showalert**

- Display the setting by port

**IVD/voip/statistics> showalert <Port>**

---

## 3.14 Tone Commands

### 3.14.1 General Commands

- Enter tone configuration function

**IVD/voip>tone**

- Help in the tone diagnostics function

**IVD/voip/tone> ?**

- Back to the voip commands

**IVD/voip/tone> ..**

### 3.14.2 Enter Function Commands

- Enter user\_defined configuration function

**IVD/voip/tone> user\_defined**

### 3.14.3 Region Commands

- Help

**IVD/voip/tone> region ?**

- Display the setting

**IVD/voip/tone> region -s**

- choose the region for CPT setting

**IVD/voip/tone> region <Region Number>**

---

Region Number	Select one country area for using VoIP feature. There is one option <b>User Defined</b> for proprietary setting.
	0 : User Defined
	1 : Australia
	2 : British (Default is 2)
	3 : Canada
	4 : China
	5 : Denmark

---

	6 : Finland
	7 : France
	8 : Germany
	9 : Hong Kong
	10 : India
	11 : Japan
	12 : Netherlands
	13 : Norway
	14 : Singapore
	15 : Taiwan
	16 : USA

### 3.14.4 Busy Tone Commands

- Help

**IVD/voip/tone/user\_defined> busy ?**

- Display the setting

**IVD/voip/tone/user\_defined> busy -s**

- Edit frequency and cadence for busy tone

**IVD/voip/tone/user\_defined> busy <Lowfreq> <Highfreq> <Ton1> <Toff1> <Ton2> <Toff2>**

<b>Low Frequency(Hz)</b>	Assign a low frequency number in Hertz unit. (unit is HZ) (Default is 350)
<b>High Frequency(Hz)</b>	Assign a high frequency number in Hertz unit. (unit is HZ) (Default is 440)
<b>Ton1(msec)</b>	The duration of the first ringing. (10msec per unit) (Default is 0)
<b>Toff1(msec)</b>	The silence duration after the first ringing. (10msec per unit) (Default is 0)
<b>Ton2(msec)</b>	The duration of the next continuous ringing. (10msec per unit) (Default is 0)
<b>Toff2(msec)</b>	The silence duration after the next continuous ringing. (10msec per unit) (Default is 0)

### 3.14.5 Caller ID Commands

- Help

**IVD/voip/tone/user\_defined> callerid ?**

- Display the setting

**IVD/voip/tone/user\_defined> callerid -s**

- Edit caller id type

**IVD/voip/tone/user\_defined> callerid <Type>**

<i>Type</i>	
	0: North America
	1: JAPAN
	2: ETSI (Default is 2)
	3: DTMF

### 3.14.6 Congestion Tone Commands

- Help

**IVD/voip/tone/user\_defined> congestion ?**

- Display the setting

**IVD/voip/tone/user\_defined> congestion -s**

- Edit frequency and cadence for congestion tone

**IVD/voip/tone/user\_defined> congestion <Lowfreq> <Highfreq> <Ton1> <Toff1> <Ton2> <Toff2>**

### 3.14.7 Dial Tone Commands

- Help

**IVD/voip/tone/user\_defined> dial ?**

- Display the setting

**IVD/voip/tone/user\_defined> dial -s**

- Edit frequency and cadence for dial tone

**IVD/voip/tone/user\_defined> dial <Lowfreq> <Highfreq> <Ton1> <Toff1> <Ton2> <Toff2>**

### 3.14.8 Ringing Tone Commands

- Help

**IVD/voip/tone/user\_defined> ringing ?**

- Display the setting

**IVD/voip/tone/user\_defined> ringing -s**

- Edit frequency and cadence for ringing tone

**IVD/voip/tone/user\_defined> ringing <Lowfreq> <Highfreq> <Ton1> <Toff1> <Ton2> <Toff2>**

<b>Lowfreq</b>	(unit is HZ) (Default is 440)
<b>Highfreq</b>	(units is HZ) (Default is 480)
<b>Ton1</b>	(10msec per unit) (Default is 0)
<b>Toff1</b>	(10msec per unit) (Default is 0)
<b>Ton2</b>	(10msec per unit) (Default is 200)
<b>Toff2</b>	(10msec per unit) (Default is 400)





# 4

## IVD Master Commands

This chapter is divided into the following sections,

- Section 4.1: The general Configuration of IVD Master
- Section 4.2: Interface Stack (instance number)
- Section 4.3: How to Save the Latest Configuration
- Section 4.4: How to Remote Upgrade Full Image
- Section 4.5: Wizard Commands

---

### 4.1 The General Configuration of IVD Master

In addition to the SNMP management, users can use commands to configure the IVD Master. Users can telnet on the IVD Master and use the following two ways. One is console interface; another is telnet by management port.

The IVD Master's console interface will be connected to PC RS-232 serial port. Users can use terminal emulation software configured by the following parameters.

- VT100 terminal emulation
- 9600 bps
- No parity, 8 data bits, 1 stop bit
- No hardware flow control

Users can call type '?' for help. The "**Admin>**" symbol is just only a prompt.

Another tool for command interface is management port via Telnet. The PC should be the same subnet as IVD Controller. The default IP address is **172.16.1.2**. Users can also use the following commands to check IP and MAC address in IVD Master. The default login name is "**admin**", password is "**1234**".

### 4.1.1 Configure the IP Address

Users can use the following commands to configure the IP address for the MGN or UP-LINK interfaces

- Enter network directory

**Admin> network**

- Help

**Admin/network> staticIP ?**

- Display the settings

**Admin/network> staticIP -s**

- Edit the IP address

**Admin/network> staticIP <ip> <netmask> <gateway>**

### 4.1.2 Upgrade Firmware

Users can use the following commands to upgrade new firmware.

- Prepare a TFTP server on a host
- Put the firmware (ipdslam.all for example) in the right directory of the TFTP server

- Enter system directory

**Admin> system**

- Execute the firmware upgrading

**Admin/system> upgrade <ServIP> <FirmName>**

- Reboot the Controller to run the new firmware

**Admin/system> reboot**

- After rebooting, check the firmware version

**Admin/system> basicInfo**

### 4.1.3 Save the Configuration

Users can use the following command to save the current configuration.

**Admin> commit**

## 4.1.4 Connect to DSL Module

Users can login to DSL module in master or slave units using the following command. Once entering into DSL module, the command described in section “DSL Command List” can be used.

- Login to DSL module in master via serial channel

**Admin> dsl -c**

## 4.1.5 ECB Service

User can use ECB service via IVD Master. The procedures are as below.

**Step 1. Enable ECB function in Master.**

**Admin> service ecb on**

**Step 2. Configure an IP address for ECB service**

**Admin> service snmp ?**

**Full Name:**

**SNMP service setting**

**Description:**

**Syntax:**

<b>snmp -l</b>	<b>(Display the community setting)</b>
<b>snmp -c &lt;CommRO&gt; &lt;CommRW&gt; &lt;CommTrap&gt;</b>	<b>(Edit the community setting)</b>
<b>snmp -p &lt;TrapPort&gt;</b>	<b>(Edit the snmp trap port)</b>
<b>snmp -s</b>	<b>(Display the traphost entries)</b>
<b>snmp -a &lt;HostIP&gt;</b>	<b>(Add the traphost entry)</b>
<b>snmp -e &lt;EntryIdx&gt; &lt;HostIP&gt;</b>	<b>(Edit the traphost entry)</b>
<b>snmp -d &lt;EntryIdx&gt;</b>	<b>(Delete the traphost entry)</b>
<b>snmp -D</b>	<b>(Delete all the traphost entries)</b>
<b>snmp on/off</b>	<b>(Turn on/off the SNMP service)</b>

**Parameters:**

<b>&lt;CommRO&gt;</b>	<b>Octets string(maxlen=64)</b>
<b>&lt;CommRW&gt;</b>	<b>Octets string(maxlen=64)</b>
<b>&lt;CommTRAP&gt;</b>	<b>Octets string(maxlen=64)</b>
<b>&lt;TrapPort&gt;</b>	<b>Integer(1..65535,default:162)</b>
<b>&lt;EntryIdx&gt;</b>	<b>Integer(1..255)</b>
<b>&lt;HostIP&gt;</b>	<b>IP Address</b>

**Use service *snmp -a <HostIP>* to setup an IP address for ECB service destination.**