

Readme First

Important : You **have to** register and activate your router for using the functions of anti-intrusion and anti-virus after set up your router for Internet access through Quick Start Wizard (please refer to **Quick Start Guide** for detailed information).

1 Creating and Activating an Account

1. Open a web browser on your PC and type **http://192.168.1.1**. A pop-up window will open to ask for username and password. Do not type any word on the window and click **OK**.
2. From the router's web page, please open **System Maintenance >>Signature Upgrade**.
3. Click the **Activate** link from the **Signature Upgrade** web page. A **Relogin** page will be shown on the screen.
4. On the right column of **Not Registered Yet?**, click the **Click here** link. On next page, please check the box to confirm that you accept the Agreement and click **Accept**.
5. Type your personal information in this page and then click **Continue**.
6. Choose proper selection for your computer and click **Continue**.
7. Check to see the confirmation email with the title of **New Account Confirmation Letter from www.vigorpro.com**.
8. Click the **Activate my Account** link to enable the account that you created. A screen will be shown to verify the register process is finished. Please click **Login**.
9. When you see the **Relogin** page, please type in new account and new password in the fields of **UserName** and **Password**. Then type the code in the box of AuthCode according to the value displayed on the right side of it.
10. Then, click **Login**. Your account has been activated. Now, please register for your vigor router in advance.

2 Registering Your Router

1. Open a web browser on your PC and type **http://192.168.1.1**. A pop-up window will open to ask for username and password. Do not type any word on the window and click **OK**.
2. From the router's web page, please open **System Maintenance >>Signature Upgrade**.
3. Click the **Activate** link from the **Signature Upgrade** web page. A **ReLog** page will be shown on the screen. Please type new account and password that you created previously. And click **Login**.
4. On the page of **Device Registration**, please click **Add** to access into next page.
5. Type in **Nick Name** (for the router) and choose the right purchase date from the popup calendar. Then click **Submit**.
6. Click **OK** to leave this web page and return to **My Product** web page on www.vigorpro.com.
7. On the web page of **My Product**, you can find a list of the devices that you add with the above steps. Currently, you just have added the router. Please click the serial number link.
8. From the **Device's Service** section, click the **Activate** button for AI-AV service.
9. In the following page, please click the DT-DT or DT-KL radio button according to the type of your service provider. The default setting is DT-KL.
10. Next, please type the activation date for this trial version. Move the mouse to the inserting box and click it. A popup calendar will appear. Select the date that you activate this version.
11. Click **Register** when you finish choosing the date. A service activation screen will appear. Please click **Close**.
12. Return to **Signature Upgrade** page of the router's web configurator (<http://192.168.1.1>). The start date and expire date for the license are shown in this page.

讀我

重要訊息：在您經由 Quick Start Wizard 完成路由器上網之基本設定後，您**必須**上網註冊並啟動您的路由器，始可使用路由器之防毒及防駭等功能。(若您需要更詳盡的內容請參考路由器之快速入門手冊)。

1

建立並啟用帳號

1. 請開啓瀏覽器並輸入 <http://192.168.1.1>，系統會要求您輸入使用者名稱及密碼，請勿輸入任何字元並按確認。
2. 自路由器設定網頁中，開啓 **System Maintenance >>Signature Upgrade**。
3. 自 **Signature Upgrade** 網頁中按下 **Activate** 連結，Relogin 頁面將顯示於畫面上。
4. 按右側還未註冊一欄中的[請按此處](#)。並在開啓的頁面中，勾選同意方塊及按下**接受**按鍵。
5. 輸入個人資訊並按**繼續**。
6. 選擇適合您電腦的選項再按**繼續**。
7. 接下來請到您的郵箱中檢查一封標題為 New Account Confirmation Letter from www.vigorpro.com 的郵件。
8. 按下 **Activate my Account** 連結，啟動您剛剛所建立的帳號，螢幕將出現註冊過程已完成之畫面，請按**登入**。
9. 當您看到 **Relogin** 頁面，請在**用戶名稱**和**密碼**欄位中輸入新的帳號及密碼，然後在**認證碼**一欄中輸入右邊圖片顯示字元。
10. 接著請按**登入**，您的帳號以完成啟動，現在請繼續上網註冊您的路由器。

2

註冊您的路由器

1. 請開啓瀏覽器並輸入 <http://192.168.1.1>，系統會要求您輸入使用者名稱及密碼，請勿輸入任何字元並按確認。
2. 自路由器設定網頁中，開啓 **System Maintenance >>Signature Upgrade**。
3. 自 **Signature Upgrade** 網頁中按下 **Activate** 連結，Relogin 頁面將顯示於畫面上。請輸入您剛剛所建立的帳號與密碼，然後按**登入**。
4. 在 **Device Registration** 頁面中，請按 **Add** 進入下一個網頁。
5. 輸入 **Nick Name** (路由器專用) 並自跳出的月曆選擇正確的購買日期，輸入完並請按 **Submit**。
6. 按 **OK** 並回到 www.vigorpro.com 的 **My Information > My Product** 網頁。
7. 在 **My Product** 頁面中，您可以看見由上述步驟所新增的路由器清單，現在您已新增路由器於網頁之資料庫中，請按序號連結。
8. 在 **Device's Service** 一區中，請按 AI-AV 服務之 **Activate** 按鈕。
9. 在接下來的頁面中請按照您的服務供應商選擇 **DT-DT** 或是 **DT-KL** 按鈕，預設項目為 **DT-KL**。
10. 接著請輸入此試用版本之啟用日期，請將滑鼠移到輸入方塊並按下滑鼠按鈕，月曆將會跳出供您選擇日期。
11. 當您完成日期選擇之後，請按 **Register**，服務啟用畫面將隨即出現，按 **Close**。
12. 回到路由器之網頁設定(<http://192.168.1.1>)頁面 **Signature Upgrade**，授權之起始及到期日期將顯示其上。

重要信息：在您经由 Quick Start Wizard 完成路由器上网之基本设定后，您**必须**上网注册并激活您的路由器，**始可使用路由器之防毒及防骇等功能**。(若您需要更详尽的内容请参考路由器之快速入门手册)。

1 建立并启用账号

1. 打开您电脑的 web 浏览器并输入 <http://192.168.1.1>。将会有有一个弹出的窗口要求输入用户名和密码。请不要输入任何内容，直接点击确定即可。
2. 进入了路由器的 web 界面后，请打开**系统维护 >> 特征库升级**。
3. 点击特征库升级页面上的激活，Relogin 页面将显示于屏幕上。
4. 点击右侧 **还没有注册？**一栏中的[这里](#)。仔细阅读并确认您接受了许可使用协议，然后点击**接受**。
5. 输入个人信息并点击继续。
6. 选择合适的喜好设定，再点击**继续**。
7. 接下来请到您的邮箱中检查一封标题为 VigorPro.com New User Notification 的邮件。
8. 点击激活我的账号链接以激活您创建的账号。启动您刚刚所建立的账号，屏幕将出现注册过程已完成之画面，请按**登录**。
9. 当您看到 **Relogin** 页面，请在用户名和密码中输入您新账号的用户名和密码，然后在校验码一栏中输入右边图片显示字符。
10. 接着请按**登录**，您的账号已完成激活，现在请继续上网注册您的路由器。

2 注册您的路由器

1. 打开您电脑的 web 浏览器并输入 <http://192.168.1.1>。将会有有一个弹出的窗口要求输入用户名和密码。请不要输入任何内容，直接点击**确定**即可。
2. 进入了路由器的 web 界面后，请打开**系统维护 >> 特征库升级**。
3. 点击特征库升级页面上的激活，Relogin 页面将显示于屏幕上。请输入您刚刚所建立的账号与密码，然后按 **Login**。
4. 在 Device Registration 页面中，请按 **Add** 进入下一个网页。
5. 输入**昵称**（路由器专用）以及正确的购买日期。添加好一些基本信息后，请点击 **Submit**。
6. 点击**确定**，并回到 www.vigorpro.com 的 **My Information > My Product** 网页。
7. 在 **My Product** 页面中，您可以看见由上述步骤所添加的路由器名单。现在您已新增路由器于网页之数据库中，请点击序列号链接。
8. 在 Device's Service 一区中，点击 AI-AV 服务的 **Activate** 按键。
9. 在接下来的页面中请按照您的服务供货商选择 DT-DT 或是 DT-KL 单选框，预设项目为 DT-KL。
10. 接着请输入此试用版本之激活日期，请将鼠标移到输入方块并按下鼠标按钮，月历将会跳出供您选择日期。
11. 当您完成日期选择之后，请点击**注册**，服务激活画面将随即出现，点击**关闭**。
12. 回到路由器之网页设定(<http://192.168.1.1>)页面特征库升级，授权之起始及到期日期将显示其上。

